


Ersatzteilliste

Artikelnummer:

216073

Sprachen:

de, en



BERNER

216073

Spare parts

Nr.	Code	Berner Art.	Description
1	AM70.060	244078	Shaft holder
2	AM70.020	244081	Half-case spring side
3	7000.038 (2)	244085	Cable guide roller
4	500.090 (2)		Pin bracket
5	AM70.070	244077	Bracket
6	7000.040		Spring shaft
7	AM70.056	244079	Spring case cover
8	AM70.140	244155	Spring
9	AM70.054		Half-Reel Spring Side
10	7000.032		Half-Reel Collector Side
11	7000.050	244058	Collector
12	500.033		Cable clamp
13	PRO210.329 (2)		Brush support
14	PRO210.064 (6)		Brush spacer
15	6947.070 (2)		Washer
16	7000.380	244057	Brush
17	7000.386 (2)	244038	Brush
18	7000.384	244056	Brush
19	7000.046	244084	Ratchet
20	AM70.010	244082	Half-case collector side
21	7000.048	244083	Ratchet spring
22	600.008	244062	Grommet
23	831.500		Cable clamp
24	AM85.065		Spacer
25	AM70.028	244080	Cover
	AM70.308	244188	15 m - 3G2,5 cable